



# Porch Valance Installation Instructions

PYC PORCH VALANCE INSTALLATION INSTRUCTIONS | HEADROD CLAMP MOUNT

## Porch Valance Installation Instructions - Clamps

### Tools Needed

- Tape Measure
- 1/8" Drill Bit (pilot holes)
- #2 Phillips Screwdriver

1. Determine where the width of the valance will be installed and mark each end with a pencil.
2. Install a headrod clamp 3" in from each end (pencil marks) of the valance.
3. Install remaining headrod clamps evenly throughout the width of the valance measuring clamps so they are on a level plane.
4. If white fiberglass headrod is cut into sections for shipping, use couplings provided to connect the sections together into one length. Use gorilla glue or similar to ensure coupling remains in place.
5. Slide fiberglass headrod through pocket on top of the valance.
6. Loosen wingnuts on clamps. Insert the valance with the headrod inside the pocket into the clamps.
7. Leave wingnuts loose, you can slide the valance back and forth until in correct position.
8. When valance is in the correct position, tighten wingnuts.



Above view should be from the inside of the porch so no hardware shows from the outside.

# PYC Awnings