



Installation Instructions

PYC PORCH ROLLER CURTAINS | UP TO 8' 11" WIDE | TRACK MOUNT

**See Videos on our Youtube Channel - PYC Awnings
Up to 8' 11" Wide**

Mounting Track:

1. Drill pilot holes in track using a 3/16" bit one inch from each side then space evenly every 12" - 15". Screws provided are #8 x 3/4" Pan Head Sheet Metal Screws, full thread, self tapping for wood or metal applications.
2. Mount Track where you started you height measurement centering the track where curtain will be located. Track can be mounted as ceiling or wall mount. Track over 90" will be cut for shipping purposes. Butt together for one length.

Mounting Pulley & Rope:

3. Mount D-Rings behind curtain under track, 10" in from each side so rope will fall behind the curtain. *You may also choose to run the rope behind the track (Underneath) and mount D-Rings that holds rope above track below eye hooks with pulleys.
4. Mount eye hooks with pulleys 10" in from each side directly above track (Pulleys & Cleats as shown can be reversed to roll the curtain up on the left side).
5. Tie one rope to each D-Ring. Rope will be labeled single pulley & double pulley. Let rope drop to floor.
6. Slide Curtain into track. Rope should be behind the curtain. Slide in galvanized pipe into pocket above flap. Pipes over 90" will be cut for shipping purposes. Use coupling with thread locker provided to make one length.

Stringing Instructions:

7. Starting with the single pulley, pull rope under galvanized pipe then thread through double pulley above and across and through double pulley down to cleat.
8. Next at double pulley, pull rope under galvanized pipe then thread through the double pulley above and down to cleat.
9. You will have tow ropes on cleat side. With curtain down, tension ropes together and tie knot. Cut any extra rope off. You can use a lighter to melt and seal the ends of ropes.

