



PYC AWNINGS

How to Measure a Retractable Fabric Valance



1. Measure Width of Fabric Valance - **Order Fabric width, Not Frame Size**
2. Measure Valance Drop/Height 6", 7" or 8". (This is a personal preference)
3. Choose Waves or Straight.

How to Install a Retractable Fabric Valance



Frame will have a track that the valance slides into. The new Valance will have an insert sewn on the top.

1. Remove End Cap.
2. Slide out old Valance.
3. Slide in New Valance.
4. Replace End Cap.

